



Gammacolor s.r.l.  
Via Zeuner, 5 20822 Seveso (MB) Italy  
tel. +39 0362550550 fax +39 0362551915  
email info@gammacolorsrl.com



Associazione Tessile e Salute  
Azienda associata

p.IVA 00736390964 C.F. 02639210158 c.c.i.a. Milano n. 927455 Codice ISS azienda 00736390964

## MICROEMULSIONE MS

code ME001MIMS

### GENERAL

MICROEMULSION MS is a softening microemulsion of aminofunctional silicon.

Is studied state in order to confer to woven a light soft, dry, pleasant finish and sliding. The dealt woven ones with MICROEMULSION MS maintain the finish also in the next washings and the treatment remains more over a long time regarding the traditional cationic softening.

### CHARACTERISTICS

Physical state liquid

Smell characteristic

Color transparent

Solubility miscible in water

pH to 20°C  $6,5 \pm 0,5$

Density (20°C) g/cm<sup>3</sup>  $0,995 \pm 0,010$

Viscosity (din. to 25°C) Residual Mpas 15 - 60

Dry % :  $35,0 \pm 2,0$

### WAY OF USE

MICROEMULSION MS has been developed specifically like softening for fibers and woven. It comes used in combination or alternative to traditional cationic softening ones.

Is characterized from a softening effect permanent that hard for various washings. The effect that is obtained on the woven is soft, swollen, dry, slippery and slightly pleasant. Although its ammino-cationic nature the product does not transmit any yellowish the woven one. Is effective on many types of fibers comprised cotton 100%, cotton polyester and syntetic fibers.

MICROEMULSION MS can be applied with procedure to immersion or extraction. For impregnation to use 20 - 40 g/l

Thanks to its elevated stability to the cut forces MICROEMULSION MS can be used in all the finish systems weave them. Is advisable that the dilution happens at the moment of use and is recommended to dilute the single product in sufficient amount in order to satisfy the daily requirements.

### STABILITY AND STORAGE

MICROEMULSION MS must be used within 6 months for being able to count on the maximum efficiency. To very conserve between + 5 and + 30°C in possibly full stalks sluices. Not to leave in order much time MICROEMULSION MS in nearly empty stalks. In this case it is well to travasare the residual content in containers more little ones.

Keywords: microemulsion, softener, siliconic, silicone, emulsion, soft hand, full hand, slippery hand

The information contained in this data sheet is based on our present and best knowledge. However we make no warranty, whether expressed or implied, including warranties of merchantability or of fitness for a particular use or purpose. Consequently the product must be tested by the user according to his



**Gammacolor s.r.l.**  
**Via Zeuner, 5 20822 Seveso (MB) Italy**  
**tel. +39 0362550550 fax +39 0362551915**  
**email [info@gammacolorsrl.com](mailto:info@gammacolorsrl.com)**



**Associazione Tessile e Salute**  
**Azienda associata**

**p.IVA 00736390964 C.F. 02639210158 c.c.i.a. Milano n. 927455 Codice ISS azienda 00736390964**

needs and his production and application conditions and purposes. Neither do we assume any responsibility for infringement of third parties patent rights which may arise from the use of the product. For industrial use only.

Information : e-mail [info@gammacolorsrl.com](mailto:info@gammacolorsrl.com)